





02 Product Size




03 Product Adjustment




Rotate in the direction of the arrow to replace the collet




Adjust the chuck rotation tightness




Use large allen key
Adjust vertical tightness



Use large allen key
Adjust vertical tightness



Use small allen key
Adjust vertical tightness



Replace & Adjust Base